

POST STYLE COMFY CALF SUITES

INSTALLATION INSTRUCTIONS



Installation or product problems? Call 1-800-260-5314

POST STYLE CCS - 06/08/2012

COMFY CALF SUITES - POST STYLE




Congratulations on the purchase of Comfy Calf Suites! These instructions will guide you through the installation process and identify parts and accessories so please read through them and save them for future reference.

ILLUS.	DESCRIPTION	PART #
1	PLASTIC CAP 1.5" X 72" (OR 96" LG)	2013130-72 / 2013130-96
2	PLASTIC PLANK 10" X 72" LG (OR 96" LG)	2013030-72 / 2013030-96
3	BOTTOM PLUG / PLANK 20' LG (cut to size)	2013220
4	GALVANIZED 24" FRONT (2 HOLE) (36" OC PEN)	1241136
	GALVANIZED 30" FRONT (2 HOLE) (42" OC PEN)	1241142
	GALVANIZED 36" FRONT (2 HOLE) (48" OC PEN)	1241148
5	GALVANIZED 2-WAY CALF LATCH	1240100
6	GALVANIZED DBL PAIL HOLDER ONLY	1241210A
7	PLASTIC CALF PAIL (WHITE)	1235033
8	STAINLESS STEEL CALF CHANNEL (20 GA) 41" HIGH	1240041
	51" HIGH	1240051
9	HDW PKG (POST SUITE) INCL U-BOLT, EYE PIN & HANDLE	1240100HDW
10	STAINLESS STEEL 24" MOUNT CHANNEL / CALF SUITE	1240226
11	60" GALVANIZED DOUBLE CALF SUITE POST	1240200
12	CALF SUITE BOLT ON GAP FILLER	1240222

ILLUSTRATION 1

9 1240100HDW HDW PKG (EYE PIN, U-BOLT & HANDLE)



INSTALLATION:

Step #1: Install handle to front channel (2 flange nuts on outside and 2 nylon locks on inside of channel). ***TIGHTEN***. Snap planks together for dividers, install front and back channels, then snap on top cap. Drill through plastic with a 1/4" bit, then fasten channels with 1/4" x 2 1/2" hex bolts.

Step #2: Anchor front posts to floor and 24" SS channels to the back wall at EXACTLY 48"OC, 42"OC OR 36"OC to match your fronts.

TIP: When mounting posts, note which way your gate will swing out for animal flow.

Note: With our 2-way latch, you can always open gate into the pen.


Step #3: Slide divider panel between double post and into the back channel. Drill 1/2" hole just behind the post and insert eye pin to keep the divider in place.

Step #4: Install front gate and block post up so it is level, then attach latch to post with 2 U-bolts.

Step #5: Install pail holder with 2 washers per bolt between front and pail holder.

Step #6: Install **OPTIONAL** accessories (shown on back page).

VENTED BACK WALL INSTALLATION:



Step #1: Lag one channel post where you are starting your back wall.

Step #2: Snap together two back wall planks. Snap top cap on the planks.




Step #3: Slide the planks into the channel post




Step #4: Drill into plastic planks with ¼" bit. (Make sure to star the hole coming from the front and the back. Don't try to go all the way through. You may not line the drill up with the hole on the backside.



Step #5: Fasten $\frac{1}{4}$ " x 2 - $2\frac{1}{2}$ " hex bolt and tighten.




Step #6: Slide the other channel post on to the other end of the plank. (**Do not fasten to post yet.**)






Step #7: Slide the rails in the holes at the tip of the posts.



Step #8: Repeat step #4 and #5 and drill holes and fasten with bolts.







Step #9: Attach receiving channel with U-Bolts. (The channel should be attached to the bottom rails and on the inside of the calf suite)


FINISHED VENTED BACK WALL





COMFY CALF SUITES - POST STYLE PARTS:


1241120 CALF HEAD HOLE REDUCER

OO
OO
OO












PART NUMBER	DESCRIPTION
2013030-72	10" HIGH PLANK X 72" LG
2013030-96	10" HIGH PLANK X 96" LG
2013130-72	TOP CAP X 72" LG
2013130-96	TOP CAP X 96 " LG
CALFCARD-50	PKG OF 50 CALF SUITE RECORD CARDS
1235033	PLASTIC CALF PAIL (WHITE)



1240100HDW HDW PKG/POST SUITE INCL HANDLE				
PART NUMBER	DESCRIPTION	QTY		
2060892	CARD HOLDER CLIP	1		
1240250A	HANDLE ONLY 5" I.D. X 2.125" LG	1		
20-6A	U-BOLT ONLY 1/75" IDX 2 9/16" L	2		
1240221	ULTRASEAL EYEBOLT 3 3/4" LG	1		
HP4	HAIR PIN (HP4)	1		
BOL3 / 8-11 / 4H	+3/8 - 16 X 11/4 HEXBOLT US	2		
NUT3 / 8FL	3/8" - 16 FLANGE NUT ULTRASEAL	2		
NUT3/8LN	3/8 - 16 N.I. LOCK NUT, US	9		
WAS3 /8	+3/8" FLAT WASHER, US	4		
BOL1 / 4 - 21 / 2HSS	1 / 4 - 20 X 2 - 1 / 2 SS HEXBOLT	6		
NUT1 / 4LSS	1 / 4 - 20 N.I. LOCK NUT SS 304	7		

OPTIONAL ACCESSORIES





ONE PIECE STAINLESS PAIL DIVIDER

(1241280SS-ND) (Item #1 in above diagram)

Step #1: Insert bolts through holes in pail holder.

Step #2: Fasten nut and washer.


SS CALF PAIL HOLD DOWN (NO ANGLE) (1241011) (Item #4 in above diagram)


Step #1: Remove nut washer and spring.

Step #2: Install hold down through hole in pail holder.

Step #3: Install spring, washer and nut.

REMEMBER TO PUT TWO WASHER SPACERS BETWEEN PAIL HOLDER & FRONT









Please visit **www.comfycalfsuites.com** for more information on our Comfy Calf Suites and **www.canarm.com** for detailed information on all our Dairy and Ventilation products.