CANARMNA[®] LED CEILING/WALL TRACK LIGHTING

LCW211A02 LCW211A03 10/20




Our service team is ready to answer your questions...

SAFETY PRECAUTIONS:

- 1. TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.
- 2. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- 3. CONNECT THE GROUND WIRES (BARE COPPER OR GREEN) FROM YOUR FIXTURE TO THE GROUND WIRE (BARE COPPER OR GREEN) OR GROUND SCREW IN THE ELECTRICAL BOX.
- 4. TO CLEAN THE FIXTURE, TURN OFF THE POWER, WAIT FOR IT TO COOL, AND WIPE THE FIXTURE WITH A CLEAN, SOFT CLOTH.


NOTE: Product may not look exactly as shown in figures.

INSTALLATION:



 1_{\circ} Attach nipple to mounting bracket. Adjust so it will clear hole in back of fixture and then lock nipple in place with hexnut. Mount the mounting bracket to electrical box using electrical box screws (not included).

 $\mathbb{2}_{\circ}$ Connect the ground wires (bare copper or green) from your fixture to the ground wire (bare copper or green) or ground screw in the electrical box. Attach the black wire from the light fixture to the black wire in the electrical box. Attach the white wire from the light fixture to the white wire in the electrical box. **NOTE: Do not disconnect** any pre-wired connections.



 \mathfrak{Z}_{\circ} Once connections of wires are completed, carefully tuck wires and wire nuts into the electrical box making sure no bare wire (on the black and white) is visible at the wire nuts.

 4_{\circ} Secure the pan to the nipple tightening by star washer and hex nut. Screw the finial to the nipple.

These LED lights are dimmable:

dimmable	Model#	MAX rated wattage	Suitable dimmer
	LCW211A02	12W	LEVITON# 742-6672-HLW , 722-6674-PDW MAX 150 W, Lutron # SCL-153PH-WH MAX 150 W
	LCW211A03	14W	